



Product Specification:

Product Weight: 12–20 kg
Power Supply: USB 5V DC (built-in replaceable lithium-ion battery: 18650)
Drive: Electric motor

User Instructions:

Setting the default password: The default password to open: **1234#**

To change the password: Enter: ***old password#new password#**

If the "OK" light turns on, the password was successfully changed.

Password should be 4 to 6 digits long.

Always confirm and test the new password before closing the drawer.

Example: To change the password from 1234 to 8888, enter:
***1234#8888#**. Then use **8888#** to open.

Note:

Three incorrect password attempts will trigger an audible alarm: "DI DI DI".

No interaction for 10 seconds will activate power saving mode.

Charging Function:

The product uses a Micro USB or Type-C connector.

Can be charged using a power bank or phone charger.

Blue light = charging; Green light = fully charged

Do not push or pull the drawer while charging – it may

damage the port!

When the battery level drops below 20%, the "BAT" light flashes every second.

Final Tips:

Keep the emergency key – it allows access in case of problems.

Do not store valuables – this is a simple password drawer.

Charge according to CE/CUL/TUV standards (5V 0.5A – 5V 2A).

The company is not responsible for any consequences of improper use.

LED Indicators and Button Functions: Star (*) button: Press to enter the password. ("Any key" lights up)

Confirmation (#) button: Press to confirm the password "OK" (green light); Drawer opened "ERR" (red light); Error –

incorrect password or system error "BAT" (flashing light); Low battery – needs to be charged