MOUNTING INSTRUCTION F/LOCK #2740



#2740 MODEL

W = Inside width of frame
GW = Glass width
H = Inside height of frame
GH = Glass height

With frame and high bottom rail (like on picture):

$$GW = ((W - 2{,}50\ mm) + 30\ mm) \times 0{,}5$$

FRAME — OVERLAY

With bumpers at the sides deduct 10 mm from the GW result.

$$GH = H - 40\ mm$$

PROFILE + AIR.

Without frame and with low bottom rail:

$$GW = (W + 30\ mm) \times 0{,}5$$

OVERLAY

With bumpers at the sides deduct 10 mm from the GW result.

$$GH = H - 32\ mm$$

PROFILE + AIR.